

Digital TV (DTV) Transmission Frequency

RELAY STATIONS	DTV BOUQUET 1		DTV BOUQUET 2		DTV BOUQUET 3	
	Channel No	Frequency (MHz)	Channel No	Frequency (MHz)	Channel No	Frequency (MHz)
Baie du Cap	53	730	50	706	51	714
Bar le Duc	58	770	45	666	38	610
Bel Air	57	762	60	786	48	690
Butte aux Papayes	48	690	43	650	46	674
Chamarel	55	746	40	626	57	762
Citadelle	54	738	55	746	52	722
Coromandel	57	762	60	786	55	746
Corps de Garde	53	730	49	698	36	594
Creve Coeur	25	506	29	538	31	554
G.R.S.E.	57	762	55	746	48	690
Juraçon	30	546	34	578	35	586
Le Morne ***	50	706	43	650	46	674
Les Mariannes	58	770	55	746	53	730
Malherbes	28	530	22	482	21	474
Mont Simonet	30	546	34	666	35	586
Motte Thérèse	37	602	31	554	39	618
Plaine Paul	48	690	45	666	55	746
Pointe du Diable	38	610	30	546	36	594
Pte Jerome ***	41	634	42	642	44	658
St Hubert	52	722	31	554	41	634
Signal Mountain	30	546	34	578	35	586
Terre Rouge	57	762	60	786	58	770
Note: *** Antenna should be in a vertically polarization position.						

<i>DTV BOUQUET 1</i>
MBC 1
MBC 2
MBC 3
B TV
ZOOM
Parliament TV

<i>DTV BOUQUET 2</i>
BBC World
Bhojpuri Channel
France 24
TV5 Monde
YS TV
Cine TV

<i>DTV BOUQUET 3</i>
Syhadri
Podhigai
Saptagiri
Urdu
Kreol Channel
CCTV 4

